



Garage Door Sensor

# INTRODUCING THE SMALLEST ZIGBEE HOME AUTOMATION DEVICES IN THE WORLD







## CONTROL

### How to Install a NYCE Control Garage Door Sensor


### **STEP 1: INSTALL BATTERY**



Slide open the Garage Door Sensor's housing. Install the CR2032 battery in the top part as shown below.



### STEP 2: INSTALL DRIVER + IDENTIFY



#### Install the Sensor's driver:


- GarageSensor\_zb\_nyce\_3014.c4i
- Download driver from: www.nycecontrol.com/support or from Control4's online database
- Copy to My Documents\Control4\Drivers
- Open Composer and add the device to the project (Manufacturer = "Nyce Control")
- Identify the Sensor by pressing the button 4 times while its identify window is open.
- The Sensor's 64-bit address should appear in the identify window's text box.
- Add a Generic Garage Door Driver to the project "My Drivers\Sensors\Garage Door (Sensor)" and bind the two drivers together in Connections -> Control/AV

### STEP 3: PROPER LOCATION / ORIENTATION OF SENSOR

- Mount the Garage Door Sensor on a horizontal pane of the garage door. The Sensor should be mounted on the bottom pane (fully closed) or top pane (fully open), depending on the desired operation.
- A pair of sensors can be used on both bottom and top panes for full garage door reporting, if desired.
- Ensure that the Garage Door Sensor is oriented with the bar symbol vertically, parallel to the edge of the garage door, as shown in the diagram below on the left.

# CORRECT ORIENTATION INCORRECT ALIGNMENT Right edge of Garage Door Right edge of Garage Door


### **STEP 4: TEST THE SENSOR**



- Test the Sensor from the desired location before permanently installing it by flipping it forward as shown above, this is the same action as the garage door opening.
- Check that the icon in Navigator's or Composer's List View updates with a "Closed" and "Open" icon.


### STEP 5: INSTALL THE GARAGE DOOR SENSOR

### **OPTION 1: DOUBLE-SIDED TAPE**



Using the methods shown above, install the Garage Door Sensor bottom housing on a clean surface using the double-sided tape or the two #2 screws provided.


### **OPTION 2: #2 SCREWS**



### Notes:

- Installation on metal surfaces can reduce transmission range.
- Ensure that the device is installed in a dry location away from water, moisture and rain.





 Once you have installed the bottom housing and confirmed the Sensor is properly communicating, close the Sensor housing as shown in the diagram above.



PRODUCT FUNCTION + LED INDICATORS				
<b>Button Press</b>	LED w/Press	Action	LED Action	Description
2 Times	••	Network Status	• •	Not Joined Joined
4 Times	••••	Network Join	• •	Join Successful Join Unsuccessful
6 Times	•••••	Network Leave	• •	Leave Successful
10 Times	••••	Restore Defaults	••	Leave (if joined) and Defaults Restored
		No Action	•	Unsupported Command Network Error, retry Device Busy

